

ACCESSORIES PLAN

Standard Accessories - Optional Accessories



ATTENTION



On order specify: type of machine, serial number, item code and quantity.

A la commande: bien préciser le type de la machine, le n° de serie, la reference de pièce, la quantité.

Bei Auftragserteilung anzugeben: Maschinentype, Seriennummer, Artikel-Code, Menge.








All'ordine specificare: tipo macchina e matricola, codice e quantità del particolare.

En cada pedido hay que especificar: el tipo de máquina y su número de matrícula, el número de código de la pieza requerida y su cantidad.




Na encomenda especificar: tipo da máquina e número de série, código do item e quantidade.

Notice: The information contained in this document is subject to change without notice

STANDARD - Accessories

| | | | |
|---|---|---|--|
|  | <p>EAK0329G92A</p> <p>EAK0329G92A</p> | <p>STANDARD TOOLS FOR MH320 PRO</p> | <p>For retrofit on older tyre changers containing: eaa0332g30a rf bead tool eac0078g21a rf bead pusher tool</p> |
|  | <p>4026853</p> <p>EAA0304G52A</p> | <p>PLASTIC RIM PROTECTIONS</p> | <p>Clip-on type, to protect rim from scratches, set of 3.</p> |
|  | <p>4030319</p> <p>EAA0350G07A</p> | <p>PLASTIC PROTECTORS</p> | <p>5 Sets of plastic rim protectors for car & m/c mounting heads 4029196, consisting of 5 plastic rim protectors, 5 rear protectors, 2 M5 hex nuts</p> |
|  | <p>EAC0115G06A</p> <p>EAC0115G06A</p> | <p>PLASTIC PROTEC. FOR BEAD LEVER WAVE PLUS</p> | <p>Plastic protector for bead lever wave plus 34415</p> |
|  | <p>4029196</p> <p>EAA0329G95A</p> | <p>MOUNTING HEAD</p> | <p>With support, for retrofit on all tyre changers manufactured by snap-on in correggio protections kit 4030319</p> |
|  | <p>4030646</p> <p>EAA0351G90A</p> | <p>LIGHT ALLORY RIM PROTECTOR (FRONT PROT.)</p> | <p>for centre jaws; set of 4</p> |
|  | <p>1419</p> <p>EAA0304G16A</p> | <p>BRUSH</p> | <p>For tire lubrication</p> |



| STANDARD - Accessories | | | |
|---|--|---|---|
|  | <p>34415 EAC0097G47A</p> | <p>BEAD LEVER WAVE PLUS</p> | <p>Wave tyre lever certified by WDK, comes standard with all tyre changers Alternative for former short tyre lever 1418, ALU tyre lever 30660 and WAVE ty</p> |
|  | <p>26582 EAA0304G15A</p> | <p>BEAD BREAKER BLADE PROTECTOR</p> | <p>Plastic protection for bead breaker blade.</p> |
|  | <p>4025460 EAA0349G76A</p> | <p>5 KG LUBE BUCKET HOLDER</p> | <p>Ring to accommodate 5 kg lube bucket</p> |










OPTIONAL - Accessories

| | | | |
|---|---|--|---|
|  | <p>4031295</p> <p>EAA0358G85A</p> | <p>WDK BEAD CLAMP</p> | <p>To facilitate mounting of the upper bead, especially on low profile and stiff tires.</p> |
|  | <p>EAC0125G10A</p> <p>EAC0125G10A</p> | <p>TYRE BEAD HOLDER</p> | <p>Universal tool to hold the bead in the rim's drop center while mounting the tyre</p> |
|  | <p>4029326</p> <p>EAA0332G32A</p> | <p>TAPERED ROLL ROD FOR MH 320</p> | <p>Rod with tapered roll for MH 320 PRO. Diameter of rod is 35 mm. To be used on MH PRO manufactured from June 2006.</p> |
|  | <p>EAA0376G54A</p> <p>EAA0376G54A</p> | <p>STEEL ROLLER AND PINS FOR MOUNTING HEAD</p> | <p>Steel roller with pin for mounting head EAA0329G95A and EAA0304G35A. For mounting heads 4029196</p> |
|  | <p>EAA0440G53A</p> <p>EAA0440G53A</p> | <p>SPACER FOR BEAD BREAKER 70mm</p> | <p>Stop the bead breaker blade at a convenient distance from the pad avoiding damage to run-flat tyres - spare part -</p> |
|  | <p>EAA0440G52A</p> <p>EAA0440G52A</p> | <p>SPACER FOR BEAD BREAKER 50mm</p> | <p>Stop the bead breaker blade at a convenient distance from the pad avoiding damage to run-flat tyres - spare part -</p> |
|  | <p>EAA0440G51A</p> <p>EAA0440G51A</p> | <p>SPACER FOR BEAD BREAKER 20mm</p> | <p>Stop the bead breaker blade at a convenient distance from the pad avoiding damage to run-flat tyres - spare part -</p> |

OPTIONAL - Accessories

| | | | |
|---|--|---------------------------------------|--|
|  | EAA0393G04A EAA0393G04A | SMART BEAD SPACER - LOW PROFILE | Holds the bead in 6 positions in the drop center during tire mounting operation. To be used in conjunction with the pneumatic bead assist - B |
|  | EAA0377G23A EAA0377G23A | SMART BEAD SPACER | Holds the bead in 6 positions in the drop center during tire mounting operation. To be used in conjunction with the pneumatic bead assist. |
|  | 4029113 EAA0329G74A | SLIP-ON SHOE | To reduce gap between bead breaker blade and rubber pad; for all tire changers manufactured by Snap-on in Correggio; to handle small motorcycle an |
|  | 4026290 EAA0304G51A | ROLLER BOARD | The device facilitates the rotation of the wheels during the bead breaking operations on the ground. |
|  | EAA0426G41A EAA0426G41A | ROD WITH DISC FOR MH | Additional bead breaker disc to be used on tilting tire changers with standard MH (Mounting Helper device). Hexagonal shaft included. |
|  | 4028228 EAA0304G66A | QUICK EXCHANGE DEVICE | With plastic mounting head |
|  | 4028229 EAA0304G67A | QUICK EXCHANGE DEVICE | Including plastic mounting head for VW / Audi / Ford / Peugeot rims with protruding spokes |
|  | 4029892 EAA0344G94A | QUICK EXCHANGE DEVICE | Without mounting head to be used with all types of Snap-on car TC mounting heads. Standard on VAS 6313 C, 6314 C, 6346 C |

OPTIONAL - Accessories

| | | | |
|---|---|--|---|
|  | <p>4030564</p> <p>EAA0350G89A</p> | <p>Plus kit 05-001</p> | <p>Neutral kit for table-top tc in general consist of:</p> <ul style="list-style-type: none"> - sidewall press disc - rods with tapered roll: 35 mm - triangular bead pusher |
|  | <p>EAK0329G93A</p> <p>EAK0329G93A</p> | <p>PLUS ACCESSORIES FOR MH320 PRO</p> | <p>Containing the tools for the PLUS models as requested for WDK certification: EAA0350G39A RF PLUS BEAD TOOL, to enter the bead lever while demounti</p> |
|  | <p>EAA0408G33A</p> <p>EAA0408G33A</p> | <p>PLASTIC TYRE PROTECTOR</p> | <p>Clip-on type, to protect run-flat tyres when mounted onto steel rims, 1 off It replaces the previous P/N EAA0332G38A.</p> |
|  | <p>EAK0317G34A</p> <p>EAK0317G34A</p> | <p>PLASTIC PROTECTORS FOR EASYCLAMP II</p> | <p>consisting of: 2x8 plastic protectors for the easyclamp II jaws (= 2 sets of wear parts; each easyclamp jaw requires 2 protectors)</p> |
|  | <p>EAA0356G20A</p> <p>EAA0356G20A</p> | <p>PLASTIC PROTECTORS</p> | <p>Sets of plastic rim protectors for mounting head EAA0332G36A - rims with protruding spokes</p> |
|  | <p>EAA0372G24A</p> <p>EAA0372G24A</p> | <p>PLASTIC PROTECTORS</p> | <p>5 Sets of plastic rim protectors for m/c mounting heads 4013706, consisting of 5 plastic rim protectors, 5 rear protectors, 2 M5 hex nuts, 2 grooved pins</p> |
|  | <p>24180</p> <p>EAA0247G04A</p> | <p>PLASTIC PROTECTOR FOR TYRE LEVER</p> | <p>Specific for old tyre levers; EAA0247G02A (Standard shape) and EAA0304G14A (WAVE shape). For former tyre levers 1418 and 25946</p> |
|  | <p>4024784</p> <p>EAA0247G20A</p> | <p>PLASTIC MOUNTING HEAD</p> | <p>With support, for retrofit on all tyre changers manufactured by Snap-on - Correggio.</p> |

OPTIONAL - Accessories

| | | | |
|---|--|---|---|
|  | <p>4027646 EAA0304G37A</p> | <p>PLASTIC MOUNTING HEAD</p> | <p>With support, for VW / Audi / Ford / Peugeot rims with protruding spokes</p> |
|  | <p>4028884 EAA0329G27A</p> | <p>MOUNTING HEAD ADAPTER FOR QUICK EXCHANGE</p> | <p>To be used when the customer already owns a quick exchange device and wants to use an additional mounting head.</p> |
|  | <p>4029338 EAA0332G36A</p> | <p>MOUNTING HEAD</p> | <p>With support, for vw / audi / ford / peugeot rims with protruding spokes</p> |
|  | <p>4013706 EAA0304G35A</p> | <p>MOTORCYCLE MOUNTING HEAD</p> | <p>To be used especially with some high-performance motorcycle tyres and recommended as auxiliary tool for motorcycle tyre changers</p> |
|  | <p>4008755 EAA0247G14A</p> | <p>MOTORCYCLE BEAD BREAKER BLADE</p> | <p>Slip-on type, narrower than standard blade</p> |
|  | <p>4030648 EAA0351G92A</p> | <p>MOTORCYCLE ADAPTORS</p> | <p>for centre jaws; set of 4</p> |
|  | <p>EAA0393G08A EAA0393G08A</p> | <p>MH TRACTOR KIT</p> | <p>Tractor kit for bead depressor of PBD330, easymont pro and MH 320 pro</p> |
|  | <p>6027703 EAA0329G34B</p> | <p>MH 320 PRO</p> | <p>The black painted Mounting Helper assists the operator in the mount / demount process. Specific for tilting tyre changers.</p> |

OPTIONAL - Accessories

| | | | |
|---|--|---|---|
|  | EAK0317G96A EAK0317G96A | MAGNETIC TOOL SUPPORT | Flexible solution to position the small tools in the most comfortable place possible Maximum weight allowed: 2kg. |
|  | 4030651 EAA0351G95A | LIGHT TRUCK ADAPTORS | for centre jaws; set of 4 |
|  | 4030647 EAA0351G91A | LIGHT ALLOY RIM PROT. (FRONT +REAR PROT.) | For 20" centre jaws; set of 8 |
|  | EAK0317G95A EAK0317G95A | HOLDER FOR TYRE LUBRICANT BUCKET (MAGN.) | Flexible solution to position the bucket in the most comfortable place possible |
|  | 4026913 EAA0304G44A | EXTENSION FOR RIM DEPRESSOR | A helping device, needed when pressing down the reversed rim during wheel clamping on turntable. |
|  | 4024098 EAA0247G12A | EXTENSION FOR EXTRA LARGE WHEELS | To be used in combination with the b/breaker pn.4025386 |
|  | EAA0377G98A EAA0377G98A | EASYCLAMP II | Universal clamping jaw adaptors - Combined set of cart, scooter, motorcycle, + light-truck wheel adaptors, clamping range 15-23", wit |
|  | EAK0279G89A EAK0279G89A | CW1015 WHEEL LIFT | Capacity 70 kg Compressed air supply 8 - 12 bars To be attached to turntable tyre changers Positioned at the front side |



| OPTIONAL - Accessories | | | |
|---|---|--|--|
|  | <p>EAA0440G54A</p> <p>EAA0440G54A</p> | <p>BEAD PRESSOR W/OFFSET ROLLER</p> | <p>Off Center bead breaker roller to be used on tilting tire changers with standard MH (Mounting Helper device). Offset roller to move stand</p> |
|  | <p>EAA0440G55A</p> <p>EAA0440G55A</p> | <p>BEAD PRESSOR W/OFFSET DISC</p> | <p>Off Center bead breaker disc to be used on tilting tire changers with standard MH (Mounting Helper device). Offset disc to move stand</p> |
|  | <p>4003444</p> <p>EAA0247G70A</p> | <p>BEAD DEPRESSING TOOL MX</p> | <p>To facilitate mounting of the upper bead, especially on low profile and stiff tires</p> |
|  | <p>4025966</p> <p>EAA0304G48A</p> | <p>BEAD DEPRESSING ROLLER</p> | <p>For quick installation on mounting head Suitable for all machines manufactured after June 2002 (sr. no. starting 0702)</p> |
|  | <p>4028111</p> <p>EAA0425G64A</p> | <p>BEAD BREAKER BLADE FOR OFF- ROAD WHEELS</p> | <p>Longer blade, quick-fit on the standard blade, to avoid squeezing off-road tire sidewall</p> |
|  | <p>4029261</p> <p>EAA0328G91A</p> | <p>ADJUSTABLE BEAD BREAKER DISC</p> | <p>To break the upper bead when the wheel is onto the turntable. Only to be used in conjunction with the pneumatic bead assist.</p> |
|  | <p>4027250</p> <p>4027250</p> | <p>ADAPTOR</p> | <p>To fit steel mounting head 4026251 / 4029196, or plastic mounting heads 4024784 or 4027646 to car tyre changers of the discontinued Hofmann car t</p> |
|  | <p>EAA0410G87A</p> <p>EAA0410G87A</p> | <p>8" ADAPTORS</p> | <p>for centre jaws; set of 4, new shape also for special rims</p> |



| OPTIONAL - Accessories | | | |
|--|--|---|---|
|  | <p>19180 EAK0257G98A</p> | <p>5 KG LUBRICANT FOR TIRES</p> | <p>5 kg lubricant for tires</p> |
|  | <p>20651 EAK0257G42A</p> | <p>1 KG LUBRICANT FOR TIRES</p> | <p>1 kg lubricant for tires</p> |
|  | <p>4030649 EAA0351G93A</p> | <p>+6" ADAPTORS</p> | <p>for centre jaws; set of 4</p> |
|  | <p>4028629 EAA0304G80A</p> | <p>+4 QUICK EXCHANGE DEVICE</p> | <p>To be used in conjunction with the +4 sliding jaws</p> |

