

ACCESSORIES PLAN

Standard Accessories - Optional Accessories



ATTENTION



On order specify: type of machine, serial number, item code and quantity.

A la commande: bien préciser le type de la machine, le n° de serie, la reference de pièce, la quantité.

Bei Auftragserteilung anzugeben: Maschinentype, Seriennummer, Artikel-Code, Menge.

All'ordine specificare: tipo macchina e matricola, codice e quantità del particolare.









En cada pedido hay que especificar: el tipo de máquina y su número de matrícula, el número de código de la pieza requerida y su cantidad.

Na encomenda especificar: tipo da máquina e número de série, código do item e quantidade.




Notice: The information contained in this document is subject to change without notice

STANDARD - Accessories			
	4031295 EAA0358G85A	WDK BEAD CLAMP	To facilitate mounting of the upper bead, especially on low profile and stiff tires.
	EAA0440G53A EAA0440G53A	SPACER FOR BEAD BREAKER 70mm	Stop the bead breaker blade at a convenient distance from the pad avoiding damage to run-flat tyres - spare part -
	EAA0440G52A EAA0440G52A	SPACER FOR BEAD BREAKER 50mm	Stop the bead breaker blade at a convenient distance from the pad avoiding damage to run-flat tyres - spare part -
	EAA0440G51A EAA0440G51A	SPACER FOR BEAD BREAKER 20mm	Stop the bead breaker blade at a convenient distance from the pad avoiding damage to run-flat tyres - spare part -
	EAA0377G23A EAA0377G23A	SMART BEAD SPACER	Holds the bead in 6 positions in the drop center during tire mounting operation. To be used in conjunction with the pneumatic bead assist.
	4030564 EAA0350G89A	Plus kit 05-001	Neutral kit for table-top tc in general consist of: - sidewall press disc - rods with tapered roll: 35 mm - triangular bead pusher
	EAK0329G93A EAK0329G93A	PLUS ACCESSORIES FOR MH320 PRO	Containing the tools for the PLUS models as requested for WDK certification: EAA0350G39A RF PLUS BEAD TOOL, to enter the bead lever while demounti

STANDARD - Accessories








	EAA0408G33A EAA0408G33A	PLASTIC TYRE PROTECTOR	Clip-on type, to protect run-flat tyres when mounted onto steel rims, 1 off It replaces the previous P/N EAA0332G38A.
	4026853 EAA0304G52A	PLASTIC RIM PROTECTIONS	Clip-on type, to protect rim from scratches, set of 3.
	4030319 EAA0350G07A	PLASTIC PROTECTORS	5 Sets of plastic rim protectors for car & m/c mounting heads 4029196, consisting of 5 plastic rim protectors, 5 rear protectors, 2 M5 hex nuts
	EAC0115G06A EAC0115G06A	PLASTIC PROTEC. FOR BEAD LEVER WAVE PLUS	Plastic protector for bead lever wave plus 34415
	4029196 EAA0329G95A	MOUNTING HEAD	With support, for retrofit on all tyre changers manufactured by snap-on in correggio protections kit 4030319
	6027703 EAA0329G34B	MH 320 PRO	The black painted Mounting Helper assists the operator in the mount / demount process. Specific for tilting tyre changers.
	EAK0317G12A EAK0317G12A	LIGHT ALLOY RIM PROTECTORS	For centre-type sliding jaws - front + rear for sliding jaws with new rounded profile of the new smartSpeed / PROspeed series
	1419 EAA0304G16A	BRUSH	For tire lubrication











STANDARD - Accessories			
	<p>34415 EAC0097G47A</p>	<p>BEAD LEVER WAVE PLUS</p>	<p>Wave tyre lever certified by WDK, comes standard with all tyre changers Alternative for former short tyre lever 1418, ALU tyre lever 30660 and WAVE ty</p>
	<p>26582 EAA0304G15A</p>	<p>BEAD BREAKER BLADE PROTECTOR</p>	<p>Plastic protection for bead breaker blade.</p>
	<p>4025460 EAA0349G76A</p>	<p>5 KG LUBE BUCKET HOLDER</p>	<p>Ring to accommodate 5 kg lube bucket</p>



OPTIONAL - Accessories

	<p>EAA0470G38A EAA0470G38A</p>	<p>TYRE LEVER WITH HOOK</p>	<p>500 mm long, for use on passenger car TC</p>
	<p>EAC0125G10A EAC0125G10A</p>	<p>TYRE BEAD HOLDER</p>	<p>Universal tool to hold the bead in the rim's drop center while mounting the tyre</p>
	<p>4029326 EAA0332G32A</p>	<p>TAPERED ROLL ROD FOR MH 320</p>	<p>Rod with tapered roll for MH 320 PRO. Diameter of rod is 35 mm. To be used on MH PRO manufactured from June 2006.</p>
	<p>EAA0376G54A EAA0376G54A</p>	<p>STEEL ROLLER AND PINS FOR MOUNTING HEAD</p>	<p>Steel roller with pin for mounting head EAA0329G95A and EAA0304G35A. For mounting heads 4029196</p>
	<p>EAK0329G92A EAK0329G92A</p>	<p>STANDARD TOOLS FOR MH320 PRO</p>	<p>For retrofit on older tyre changers containing: eaa0332g30a rf bead tool eac0078g21a rf bead pusher tool</p>
	<p>EAA0393G04A EAA0393G04A</p>	<p>SMART BEAD SPACER - LOW PROFILE</p>	<p>Holds the bead in 6 positions in the drop center during tire mounting operation. To be used in conjunction with the pneumatic bead assist - B</p>
	<p>4029113 EAA0329G74A</p>	<p>SLIP-ON SHOE</p>	<p>To reduce gap between bead breaker blade and rubber pad; for all tire changers manufactured by Snap-on in Correggio; to handle small motorcycle an</p>

OPTIONAL - Accessories

	<p>4026290 EAA0304G51A</p>	<p>ROLLER BOARD</p>	<p>The device facilitates the rotation of the wheels during the bead breaking operations on the ground.</p>
	<p>EAA0426G41A EAA0426G41A</p>	<p>ROD WITH DISC FOR MH</p>	<p>Additional bead breaker disc to be used on tilting tyre changers with standard MH (Mounting Helper device). Hexagonal shaft included.</p>
	<p>EAK0341G30A EAK0341G30A</p>	<p>RIM INDEX KIT FOR 600mm DIA FLANGE</p>	<p>The kit allows the correct positioning of the jaws when working on aluminum rims with the tire still installed</p>
	<p>4028228 EAA0304G66A</p>	<p>QUICK EXCHANGE DEVICE</p>	<p>With plastic mounting head</p>
	<p>4028229 EAA0304G67A</p>	<p>QUICK EXCHANGE DEVICE</p>	<p>Including plastic mounting head for VW / Audi / Ford / Peugeot rims with protruding spokes</p>
	<p>4029892 EAA0344G94A</p>	<p>QUICK EXCHANGE DEVICE</p>	<p>Without mounting head to be used with all types of Snap-on car TC mounting heads. Standard on VAS 6313 C, 6314 C, 6346 C</p>
	<p>EAA0356G20A EAA0356G20A</p>	<p>PLASTIC PROTECTORS</p>	<p>Sets of plastic rim protectors for mounting head EAA0332G36A - rims with protruding spokes</p>
	<p>EAA0372G24A EAA0372G24A</p>	<p>PLASTIC PROTECTORS</p>	<p>5 Sets of plastic rim protectors for m/c mounting heads 4013706, consisting of 5 plastic rim protectors, 5 rear protectors, 2 M5 hex nuts, 2 grooved pins</p>


OPTIONAL - Accessories

	<p>24180 EAA0247G04A</p>	<p>PLASTIC PROTECTOR FOR TYRE LEVER</p>	<p>Specific for old tire levers; EAA0247G02A (Standard shape) and EAA0304G14A (WAVE shape). For former tyre levers 1418 and 25946</p>
	<p>4024784 EAA0247G20A</p>	<p>PLASTIC MOUNTING HEAD</p>	<p>With support, for retrofit on all tire changers manufactured by Snap-on - Correggio.</p>
	<p>4027646 EAA0304G37A</p>	<p>PLASTIC MOUNTING HEAD</p>	<p>With support, for VW / Audi / Ford / Peugeot rims with protruding spokes</p>
	<p>4028884 EAA0329G27A</p>	<p>MOUNTING HEAD ADAPTER FOR QUICK EXCHANGE</p>	<p>To be used when the customer already owns a quick exchange device and wants to use an additional mounting head.</p>
	<p>4029338 EAA0332G36A</p>	<p>MOUNTING HEAD</p>	<p>With support, for vw / audi / ford / peugeot rims with protruding spokes</p>
	<p>4013706 EAA0304G35A</p>	<p>MOTORCYCLE MOUNTING HEAD</p>	<p>To be used especially with some high-performance motorcycle tyres and recommended as auxiliary tool for motorcycle tyre changers</p>
	<p>4008755 EAA0247G14A</p>	<p>MOTORCYCLE BEAD BREAKER BLADE</p>	<p>Slip-on type, narrower than standard blade</p>
	<p>EAA0393G08A EAA0393G08A</p>	<p>MH TRACTOR KIT</p>	<p>Tractor kit for bead depressor of PBD330, easymont pro and MH 320 pro</p>



OPTIONAL - Accessories			
	31642 EAK0257G77A	MANUAL TYRE INFLATOR	Hand gauge, for tire inflation
	EAK0317G96A EAK0317G96A	MAGNETIC TOOL SUPPORT	Flexible solution to position the small tools in the most comfortable place possible Maximum weight allowed: 2kg.
	4027629 EAA0304G32A	LIGHT TRUCK ADAPTOR	For centre type sliding jaws, set of 4
	EAK0329G86A EAK0329G86A	LIGHT ALLOY RIM PROTECTORS - FRONT ONLY	For centre-type sliding jaws - front only for sliding jaws with new rounded profile of the new smartSpeed / PROspeed series
	EAK0341G18A EAK0341G18A	INTEGRAL PLASTIC PROTEC FOR SLIDING JAWS	To be used for 15" aluminium wheel best clamping: Set of 4.
	EAK0341G19A EAK0341G19A	INTEGRAL PLASTIC PROTEC FOR SLIDING JAWS	To be used for 17" aluminium wheel best clamping: Set of 4.
	EAK0341G20A EAK0341G20A	INTEGRAL PLASTIC PROTEC FOR SLIDING JAWS	To be used for 18" aluminium wheel best clamping: Set of 4.
	EAK0341G21A EAK0341G21A	INTEGRAL PLASTIC PROTEC FOR SLIDING JAWS	To be used for 19" aluminium wheel best clamping: Set of 4.






OPTIONAL - Accessories			
	EAK0317G95A EAK0317G95A	HOLDER FOR TYRE LUBRICANT BUCKET (MAGN.)	Flexible solution to position the bucket in the most comfortable place possible
	4026913 EAA0304G44A	EXTENSION FOR RIM DEPRESSOR	A helping device, needed when pressing down the reversed rim during wheel clamping on turntable.
	4024098 EAA0247G12A	EXTENSION FOR EXTRA LARGE WHEELS	To be used in combination with the b/breaker pn.4025386
	EAK0279G86A EAK0279G86A	CW1025 Wheel Lift	Capacity 70 kg Compressed air supply 8 - 12 bars To be attached to turntable tyre changers w/ racing-type cabinet
	EAA0372G25A EAA0372G25A	CRIMPED HOSE	Crimped Hose
	EAA0440G54A EAA0440G54A	BEAD PRESSOR W/OFFSET ROLLER	Off Center bead breaker roller to be used on tilting tire changers with standard MH (Mounting Helper device). Offset roller to move stand
	EAA0440G55A EAA0440G55A	BEAD PRESSOR W/OFFSET DISC	Off Center bead breaker disc to be used on tilting tire changers with standard MH (Mounting Helper device). Offset disc to move stand
	4003444 EAA0247G70A	BEAD DEPRESSING TOOL MX	To facilitate mounting of the upper bead, especially on low profile and stiff tires



OPTIONAL - Accessories			
	4025966 EAA0304G48A	BEAD DEPRESSING ROLLER	For quick installation on mounting head Suitable for all machines manufactured after June 2002 (sr. no. starting 0702)
	4028111 EAA0425G64A	BEAD BREAKER BLADE FOR OFF- ROAD WHEELS	Longer blade, quick-fit on the standard blade, to avoid squeezing off-road tire sidewall
	4029261 EAA0328G91A	ADJUSTABLE BEAD BREAKER DISC	To break the upper bead when the wheel is onto the turntable. Only to be used in conjunction with the pneumatic bead assist.
	4027250 4027250	ADAPTOR	To fit steel mounting head 4026251 / 4029196, or plastic mounting heads 4024784 or 4027646 to car tyre changers of the discontinued Hofmann car t
	4028568 EAA0329G53A	8" (ATV) AND M/C ADAPTORS # 4028567	For centre type sliding motorcycle wheels up to 23" rim diameter; set of 4 # EAA0329G52A.
	19180 EAK0257G98A	5 KG LUBRICANT FOR TIRES	5 kg lubricant for tires
	EAK0330G55A EAK0330G55A	26" MOTORCYCLE ADAPTOR KIT	Kit of 4 motorcycle adaptors EAA0481G46A to increase the capability from 12" to 26" – For sliding jaws
	20651 EAK0257G42A	1 KG LUBRICANT FOR TIRES	1 kg lubricant for tires



OPTIONAL - Accessories			
	<p>4029457 EAA0338G50A</p>	<p>+4 QUICK EXCHANGE KIT FOR SLIDING JAWS</p>	<p>+4 kit consisting of set of adaptors for sliding jaws #4029455 and +4" quick exchange 4028629; center type</p>
	<p>4028629 EAA0304G80A</p>	<p>+4 QUICK EXCHANGE DEVICE</p>	<p>To be used in conjunction with the +4 sliding jaws</p>
	<p>4029455 EAA0331G91A</p>	<p>+4 JAWS FOR SLIDING JAWS # 4029453</p>	<p>Center type, including plastic insert, set of 4</p>



